

Quick Start Guide

Servo Drives Digitax M751

(Norgren Article Numbers QE/D0140400030 and QE/D02400105) for use with the servo motors supplied by Norgren.



INDEX

| | |
|---------------------------------------------------------------------------|-----------|
| Mechanical installation | 5 |
| Selection and download of the Norgren standard parameter sets | 5 |
| Setting up a new project | 8 |
| Establish Connection via Ethernet/IP | 9 |
| Transfer of the parameter set via Ethernet/IP | 11 |
| Establish Connection via the USB/EIA485 Converter Cable | 15 |
| Transfer of the parameter set using the USB/EIA485 converter cable | 18 |
| Setting up a bootable SD-card | 22 |
| Transfer of the parameters from the SD card to the drive | 24 |
| Maximum motor torque | 24 |
| Use of Macro Files during Commissioning | 25 |
| Selection of Macro Files | 28 |
| Positioning and speed control | 30 |

This quick start guide describes the parametrization of the servo drives Digitax M751 Base (Norgren Article Numbers QE/D0140400030 and QE/D02400105) for use with the servo motors supplied by Norgren.

The Norgren standard parameter sets enable the user to quickly commission the servo drive and servo motor combinations supplied by Norgren. The standard parameter sets are available for download in the *Technical Support* section at www.norgren.com.

The basic parameters enable the following functions:

- *Pairing of servo drive and motor*
- *Setting of direction and speed of the rotation of the servo motor shaft using a potentiometer according to figure 4-30 "Default control terminal functions" in the "Installation and technical guide Digitax HD M75x Series" (digitally available at Nidec / Control Techniques at: <https://acim.nidec.com/drives/control-techniques/products/servo-drives/digitax-hd/digitax-hd-m751-base>)*
- *The servo drive will then work in "Rotational velocity control" mode*
- *The velocity control gain factors can be optimized regarding the inertia of the load if necessary*
- *To avoid unintended damage to the actuators during commissioning the standard parameter sets limit the maximum torque of the motors to 15 % of the rated torque. Depending on external loads or the direction of the desired movement, this limit may be too low for commissioning. Necessary actions to increase the motor torque are also described in this guide.*
- *The quick start guide includes three possible routes for parametrization of the drive:*
- *Setting the parameters using a computer and the Ethernet/IP-option module*
 - *Setting up a new project*
 - *Connection via Ethernet/IP*
 - *Transfer of the parameter set using Ethernet/IP*
- *Setting the parameters using a computer and the USB/EIA485 converter module*
 - *Setting up a new project*
 - *Connection using the USB/EIA485 converter module*
 - *Transfer of the parameter set using the USB/EIA485 converter module*
- *Setting the parameters using a bootable SD card*
 - *Setting up a new project*
 - *Setting up a bootable SD card*
 - *Transfer of the parameter set from the SD card to the drive*

For parametrization the "Connect Drive Commissioning Software" is necessary. It can be downloaded free of charge under the following link after registration:

<https://acim.nidec.com/drives/control-techniques/products/servo-drives/digitax-hd/digitax-hd-m751-base>

The guide for setting the parameters via Ethernet/IP can also be followed when using Ethernet based bus protocols like ProfiNet or EtherCAT. In this case the drive must be assigned an IP address manually before connecting it to the computer: The assignment must be executed using the bus master. Please consult the documentation of the respective bus systems for further information.

To include the actuators in an independently controlled PLC system, additional files like EDS- or GSDML-files may be mandatory (depending on the bus system used). These are also available for download at <https://acim.nidec.com/de-de/drives/control-techniques/products/servo-drives/unidrive-m700-servo#>.

The files available for the Unidrive M drive series are also suitable for the Digitax HD series supplied by Norgren.

When an independently controlled PLC system is used, the use of the *PLC Controlled Motion Wizard* within *Connect Drive Commissioning Software* is not advisable as the wizard overwrites parameters previously uploaded. For further guidance regarding positioning and speed control of the motors, please refer to chapters 4-6 of the *PLC Controlled Motion* guides offered by Nidec / Control Techniques.

Mechanical Installation

Execute the mechanical installation of the actuator according to the Installation and Maintenance Sheet of actuator series E/809000, E/148000 or E/149000, respectively. These are issued with the actuator. They can also be downloaded in the *Technical Support* section at www.norgren.com.

For the mechanical installation of the servo drives and cables please consult the “Installation and Technical Guide Digitax HD M75x Series”.

Selection and download of the Norgren standard parameter sets

The Norgren standard parameter sets can be found online in the *Technical Support* section at www.norgren.com.

To select the suitable parameter set use the model number of your motor. This can be found on the type label (Figure 1, example 055UDB305BAEGA)



Figure 1: Type label servo motor

For motors with Multiturn feedback there are two different cable configurations available. These are preconfigured for different revisions of the EnDat protocol. The use of both cable configurations is possible through adapted parameters. Figure 2 shows how to differentiate between both cable configurations. The SC EnDat 2.1 cable is equipped with a straight D-Sub-Plug with a separate ground line whereas the EnDat 2.2 cable features an angled plug.




Figure 2: Differentiation between possible Multiturn feedback cable configurations

Choose the parameter file according to the type number of your motor and the cable configuration used. Whether a motor with or without holding brake is used makes no difference for selecting the parameter file, see Table 1.

Table 1: Selection of the correct parameter file

| Motor part number Norgren | Motor part number Nidec (Given on the type label) | Parameter file name |
|---------------------------|------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------|
| QE/M05530/EA/09 | 055UDB300BAARA* | 055UDB30_BAARA-QE_M05530_EA-09_Resolver |
| QE/M05530/EB/09 | 055UDB300BAEMA* | 055UDB30_BAEGA-QE_M05530_EB_09_MultiTurn_SC-EnDat2_1 or 055UDB30_BAEGA-QE_M05530_EB_09_MultiTurn_EnDat2_2 |
| QE/M05530/EM/09 | 0055UDB305BAARA* | 055UDB30_BAARA-QE_M05530_EA-09_Resolver |
| QE/M05530/EN/09 | 055UDB305BAEMA* | 055UDB30_BAEGA-QE_M05530_EB_09_MultiTurn_SC-EnDat2_1 or 055UDB30_BAEGA-QE_M05530_EB_09_MultiTurn_EnDat2_2 |
| QE/M06730/JA/14 | 067UDB300BAARA* | 067UDB30_BAARA-QE_M06730_JA_14_Resolver |
| QE/M06730/JB/14 | 067UDB300BAEMA* | 067UDB30_BAEGA-QE_M06730_JB_14_Multiturn_SC-EnDat2_1 or 067UDB30_BAEGA-QE_M06730_JB_14_Multiturn_EnDat2_2 |
| QE/M06730/JM/14 | 067UDB306BAARA* | 067UDB30_BAARA-QE_M06730_JA_14_Resolver |
| QE/M06730/JN/14 | 067UDB306BAEMA* | 067UDB30_BAEGA-QE_M06730_JB_14_Multiturn_SC-EnDat2_1 or 067UDB30_BAEGA-QE_M06730_JB_14_Multiturn_EnDat2_2 |
| QE/M06730/NA/14 | 067UDC300BAARA* | 067UDC30_BAARA-QE_M06730_NA_14_Resolver |
| QE/M06730/NB/14 | 067UDC300BAEMA* | 067UDC30_BAEGA-QE_M06730_NB_14_Multiturn_SC-EnDat2_1 or |

| | | |
|-----------------|-----------------|-----------------------------------------------------------------------------------------------------------------|
| | | 067UDC30_BAEGA-QE_M06730_NB_14_Multiturn_EnDat2_2 |
| QE/M06730/NM/14 | 067UDC306BAARA* | 067UDC30_BAARA-QE_M06730_NA_14_Resolver |
| QE/M06730/NN/14 | 067UDC306BAEMA* | 067UDC30_BAEGA-QE_M06730_NB_14_Multiturn_SC-EnDat2_1 or 067UDC30_BAEGA-QE_M06730_NB_14_Multiturn_EnDat2_2 |
| QE/M08930/RA/19 | 089UDC300BAAEA* | 089UDC30_BAAEA-QE_M08930_RA_19_Resolver |
| QE/M08930/RB/19 | 089UDC300BAECA* | 089UDC30_BAECA-QE_M08930_RB_19_MultiTurn_SC-EnDat2_1 or 089UDC30_BAECA-QE_M08930_RB_19_MultiTurn_EnDat2_2 |
| QE/M08930/RM/19 | 089UDC306BAAEA* | 089UDC30_BAAEA-QE_M08930_RA_19_Resolver |
| QE/M08930/RN/19 | 089UDC306BAECA* | 089UDC30_BAECA-QE_M08930_RB_19_MultiTurn_SC-EnDat2_1 or 089UDC30_BAECA-QE_M08930_RB_19_MultiTurn_EnDat2_2 |
| QE/M11530/WA/24 | 115UDC300BAAEA* | 115UDC30_BAAEA-QE_M11530_WA_24_Resolver |
| QE/M11530/WB/24 | 115UDC300BAECA* | 115UDC30_BAECA-QE_M11530_WB_24_MultiTurn_SC-EnDat2_1 or 115UDC30_BAECA-QE_M11530_WB_24_MultiTurn_EnDat2_2 |
| QE/M11530/WM/24 | 115UDC306BAAEA* | 115UDC30_BAAEA-QE_M11530_WA_24_Resolver |
| QE/M11530/WN/24 | 115UDC306BAECA* | 115UDC30_BAECA-QE_M11530_WB_24_MultiTurn_SC-EnDat2_1 or 115UDC30_BAECA-QE_M11530_WB_24_MultiTurn_EnDat2_2 |

Setting up a new project

Open “Connect Drive Commissioning Software”. The start screen is opened. Create a new project.




Figure 3: Connect Drive Commissioning Software start screen

Choose a name and directory.




Figure 4: Setting up a new project

An empty window opens. The name of the project is shown in the top (here: “Test_Project_IMI”).

Establish Connection via Ethernet/IP

The following chapters describe setting the parameters of the servo drive using the Ethernet/IP option module. It can be purchased under the type number QE/B179000/EN.

The same steps can be followed when using Ethernet based bus protocols like ProfiNet or EtherCAT. In this case, the drive must be assigned an IP-address using an external bus master prior to connecting it to the computer. For further advice please consult the documentation of the bus systems.

To connect the drive to the computer click “Add drive” and choose “Search for new drives”. Now the local network is searched for connected servo drives.




Figure 5: Search local network for drives

All servo drives found in the search are shown. Every drive is assigned an IP address and its type is detected. In this example, one drive is connected to the network, only, see. Figure 6.




Figure 6: Adding the drives connected to the network

Select the drive that shall be connected to the project by setting the mark and confirm by clicking “OK”. The drive is now added to the project and shown in the project tree on the left hand side. Now the dashboard of one of the drives is shown in the center window, see Figure 7.




Figure 7: Project dashboard

Transfer of the parameter set via Ethernet/IP

To load a parameter set onto the drive, click the “Online” button on the dashboard as shown in Figure 8.




Figure 8: Create "online"-connection to the drive

The selected drive as well as the respective dashboard are now high-lighted in green, see Figure 9.




Figure 9: Create "online"-connection to the drive (2)

Select the drive and click “Properties” in the “View” tab. The “Drive properties” window is opened. You can compare the serial number of the drive with the connected drive, here. The serial number can be found on the type labels on top and on the side of the drive.




Figure 10: Drive properties and identification of the connected drive

To download the Norgren standard parameter sets to the drive select “download to drive” in the project dashboard, see Figure 11.




Figure 11: Download to the drive

A window opens. Navigate to the directory containing the Norgren standard parameter sets and select the appropriate parameter file. Confirm with “Open”, see Figure 12.




Figure 12: Opening a parameter file

If more than one option module is installed to the drive, a warning appears. This can be closed.




Figure 13: Warning for multiple option modules

To save the parameter set, select "Save parameters to drive" on the "Start" tab.




Figure 14: Save parameters to drive

Now the setting of the parameters is complete. Repeat the steps shown in this guide for all other drives in use.

If necessary, it is also possible to rename the drives. To do so, right-click the servo drive in the project tree. Then click "Rename" or use the "Device properties" window already open to edit the device name. In this example, the name "Drive 2.2 A" is used. This step must be executed after loading the standard parameters to the drive. Otherwise, the newly edited name will be overwritten by the standard.




Figure 15: Renaming the drive

Establish Connection via the USB/EIA485 Converter Cable

The following chapters describe setting the parameters of the drive using the USB/EIA485 converter cable. It can be purchased under the type number QE/A4500/0096.

The USB/EIA485 converter cable enables the user to establish a connection between any USB port of the computer in use and one of the EIA485 ports of the drive. Both EIA485 ports can be used.

To establish a connection to the drive, click “Add drive” and select “Search for new drive”.



Figure 16: Search local network for new devices

To search for devices that are connected using the converter cable, click the “Settings” button in the opened search window, see Figure 17.




Figure 17: Adding drives using the serial port

Check the box “Search RTU (serial)” in the RTU window, see Figure 18.




Figure 18: Searching the serial connection

Any found drives will now be listed in the search window. Every drive is assigned an IP address and its type is detected, see Figure 19.




Figure 19: Adding drives using the serial connection

Select the drive by ticking the box and confirm with “OK”. The selected drives will now be added to the project. They are now visible in the project tree. The center window now shows the project dashboard for one of the drives, see Figure 20




Figure 20: Project dashboard

Transfer of the parameter set using the USB/EIA485 converter cable

To transfer the parameter sets onto the drives using the USB/EIA485 converter cable, the same steps as described for the Ethernet/IP connection must be followed. Analogue to the setup using an Ethernet/IP connection, properties of the drive can be read and edited.

To load a parameter set onto the drive, click the “Online” button on the dashboard as shown in Figure 21.




Figure 21: Online connection to the drive

The selected drive and its dashboard are now high-lighted in green, see Figure 22.




Figure 22: Online connection to the drive (2)

Select the drive and click “Properties” in the “View” tab. The “Drive properties” window is opened. You can compare the serial number of the drive with the connected drive, here. The serial number can be found on the type labels on top and on the side of the drive.




Figure 23: Device properties and identification of the servo drive

To download the Norgren standard parameter sets to the drive select “download file to drive” in the project dashboard, see Figure 24.




Figure 24: Download to the device

A window opens. Navigate to the directory containing the Norgren standard parameter sets and select the appropriate parameter file. Confirm with “Open”, see Figure 25.




Figure 25: Opening a parameter file

If more than one option module is installed to the drive, a warning appears. This can be closed.




Figure 26: Warning for multiple option modules

To save the parameter set, select “Save parameters to drive” on the “Home” tab.




Figure 27: Save parameters to device

Now the setting of the parameters is complete. Repeat the steps shown in this guide for all other drives in use.

If necessary, it is also possible to rename the drives. To do so, right-click the servo drive in the project tree. Then click “Rename” or use the “Device properties” window already open to edit the device name. In this example, the name “Drive 2.2 A” is used. This step must be executed after loading the standard parameter set to the drive. Otherwise, the newly edited name will be overwritten by the standard.




Figure 28: Renaming the drive

Setting up a bootable SD-card

The following chapters describe setting the parameters of the drives using a bootable SD card. After parametrization the SD card may be removed from the drives. Therefore, setting up a single bootable SD card is beneficial if multiple identical combinations of servo drive and servo motor are used.

Open the “SD card manager” under “Tools & Wizards” in the “Home” tab.




Figure 29: Opening the SD card manager

Now select the „Prepare“ button.




Figure 30: Preparation of the SD card

Select the “From a parameter file” option under “Which parameters?”. Select “Bootable parameter file” as “Filetype for SD card”. By clicking the “...” button the selection window for the parameter files is opened.




Figure 31: Setting up a bootable SD card

Select the parameter file appropriate to the motor and feedback cable revision as described before. Confirm by clicking “Open”.




Figure 32: Selection of a parameter set

Now, the set-up of the bootable SD card is complete, and the SD card can be removed securely from the SD card slot of the computer.

Transfer of the parameters from the SD card to the drive

To transfer the parameter set from the SD card to the drive, the card is inserted to the SD card slot on the front of the drives. Now, a brief manual interruption of the 24 V DC connection to the drive is necessary. The drive now reboots and loads the parameters from the SD card to its internal memory.

A blinking status LED on the front of the drive indicates that a reset is necessary. To reset the drive, briefly press the reset button. Constant illumination of the LED indicates successful loading of the parameter set. Now the drive is ready for use. The SD card can now be removed from the slot.

Maximum motor torque

Parameters 4.005 to 4.007 define the motor torque limits. To avoid unintended damage to the actuators during commissioning, the Norgren standard parameter sets limit of the maximum motor torque to 15 % of the rated torque of the motor. The values of the parameters 4.005 to 4.007 can be increased after commissioning. A maximum value of 300 % of the rated torque is possible. For acceleration and deceleration differing values can be put into parameters 4.005 and 4.006. Alternatively, parameter 4.007 offers a symmetric value for both. If differing values are selected, the smaller value is used.

Use of Macro Files during Commissioning

Depending on the desired functionality of the Norgren ELION actuator and the configuration of peripheral systems to the drive several parameters need to be set in addition to the standard parameter sets. To simplify this procedure, a range of Macro Files is available. These can be added to the configuration in Connect Software. The following abstracts show how to load the Macros into connect and how to download the settings to the drive. Following this, the Macro Files provided by Norgren are listed and commented on in more detail.

To include the macro files into the current project, right click on “Macro Files” in the “Project” Window in Connect:




Figure 33: Add macro files to the project

Now copy all desired macro files from the selected folder into the project:




Figure 34: Select Macro Files

The selected macro files are now shown in the macro file folder in the Project window in Connect.




Figure 35: Selected Macro Files in Connect

Now, the parameter changes defined by each macro file can be executed by downloading the selected file to the drive (see Figure 36). To do so, the drive must not be enabled, i.e. at least one of the STO input signals (parameters #08.009 and #08.040) must be *low*.




Figure 36: Download Macro to the Drive

Afterwards, all parameter changes should be saved in the drive to transfer them to the non-volatile memory of the drive:




Figure 37: Save parameter changes

Selection of Macro Files

Table 2 gives a short description for the Macro Files available for the drive range offered by Norgren. To simplify the selection of the necessary Macro Files for the application, please refer to the guidance given in the *MacroSelection* sheet available for download from the Norgren website (www.norgren.com). Figure 38 gives an overview where the different terminals mentioned in Table 2 can be found.

Table 2: List of Macro Files

| Macro File | Description |
|--------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| MA751-01_HoldingBrakeActuation | <ul style="list-style-type: none"> - Enables the use of the holding brake if necessary - Delay times are set according to the mechanical behaviour of the holding brake |
| MA751-02_AMC_enable | <ul style="list-style-type: none"> - Enables the use of the Advanced Motion Controller - Simplifies settings for positioning, speed ramps, referencing the actuator etc. |
| MA751-03_1_HomingMechanicalEndStop | <ul style="list-style-type: none"> - Enables the use of a mechanical end stop of the actuator connected to the motor for homing - Speed of the actuator during the homing sequence is limited to 10 rpm - Torque thresholds for hard stop detection are set |
| MA751-03_2_HomingPositionSwitches | <ul style="list-style-type: none"> - Enables the use of a limit switch for the referencing procedure - Speed of the actuator during the homing sequence is limited to 10 rpm. |
| MA751-04_1_HomingTerminalControlUsingHardwareLimitSwitchesConfig | <ul style="list-style-type: none"> - Requires an SI-IO option module mounted in Slot 2 of the drive - Sets the "Run Forward" parameter to Digital Input 4 of the drive - Limit switches are enabled and connected to DI 2 and 3 of the SI-IO module - Parameters #06.035 and #06.036 (limit switches) are connected through to the homing function |
| MA751-04_2_HomingBusControlWithHardwareLimitSwitchesConfig | <ul style="list-style-type: none"> - Does not require SI-IO option module - Requires Bus option module (e.g. ProfiNet or EtherCAT) - Digital Input 4 and 5 are set to the positive and negative limit switch, respectively - Homing limits are set to the limit switches |
| MA751-04_3_HomingTerminalControlWithoutHardwareLimitSwitchesConfig | <ul style="list-style-type: none"> - Run Forward is set to Digital Input 4 - Other input terminals are not used |
| MA751-05_1_HomingMechanicalEndStopPositiveLimit | <ul style="list-style-type: none"> - Homing mode is set to positive limit (with respect to motor rotation): - Motor end stop for E/809***/*/*/*/* and E/148***/*/*/*/* - Far end stop for E/809***/*/*/*/*, E/149*** and E/148***/*/*/*/* |
| MA751-05_2_HomingMechanicalEndStopNegativeLimit | <ul style="list-style-type: none"> - Homing mode is set to negative limit (with respect to motor rotation) - Far end stop for E/809***/*/*/*/* and E/148***/*/*/*/* - Motor end stop for E/809***/*/*/*/*, E/149*** and E/148***/*/*/*/* |
| MA751-06_1_BrakingResistor_50W | <ul style="list-style-type: none"> - Sets the parameters to include the 50 W braking resistor (Norgren part number QE/A9500/1049) |
| MA751-06_2_BrakingResistor_100W | <ul style="list-style-type: none"> - Sets the parameters to include the 100 W braking resistor (Norgren part number QE/A1220/2801) |
| MA751-07_1_HardwareLimitSwitches_NO_BusControl | <ul style="list-style-type: none"> - DI 4 and 5 of the drive or DI 2 and 3 of the SI-IO module are used for the limit switch signals - Sets digital input signals for the limit switches to use Normally Open limit switches |
| MA751-07_2_HardwareLimitSwitches_NC_BusControl | <ul style="list-style-type: none"> - For use with field bus systems, only - DI 4 and 5 of the drive or DI 2 and 3 of the SI-IO module (if mounted to slot 2 of the drive) are used for the limit switch signals - Sets digital input signals for the limit switches to use Normally Closed limit switches |
| MA751-07_3_HardwareLimitSwitches_NC_TerminalControl | <ul style="list-style-type: none"> - For use with terminal control - DI 4 of the drive is used for the Run Forward signal - DI 2 and 3 of the SI-IO module (mounted in slot 2 of the drive) are used for limit switch signals |
| MA751-08_1_FeedbackCable_EnDat_2_2RevOrResolver | <ul style="list-style-type: none"> - Resets the feedback system for the use of an EnDat 2.2 Cable revision (Multiturn) or a Resolver feedback system (See Figure 2) |

MA751-08_2_
FeedbackCable_EnDat_2_1Rev_
MotorSize55-67

- Sets the feedback system for the use of an SC EnDat 2.1 Cable revision (see Figure 2) in combination with motor sizes 055 and 067 (Norgren motor type numbers QE/M05530/EB/09, QE/M05530/EN/09, QE/M06730/JB/14, QE/M06730/JN/14, QE/M06730/NB/14, and QE/M06730/NN/14)




Figure 38: Digital Inputs of the Drive and SI-IO Option Module

Positioning and speed control

The servo motors and drives supplied by Norgren offer a comprehensive positioning and speed control capability. Rotational movement of the motor shaft is calculated in *User Units* that are proportional to the linear distance travelled by the actuator piston rod or carriage, respectively. To simplify the conversion calculations, a *Positioning Calculation* tool is also part of the download package. The tool offers a conversion between the parameters given in Table 3 depending on the actuator size and configuration.

Table 3: Conversion Table

| Parameter | Conversion |
|-----------------------------|--------------------------------------------------------------------------|
| Stroke (distance travelled) | mm → UU |
| Velocity | $\frac{\text{mm}}{\text{s}} \rightarrow \frac{\text{UU}}{\text{ms}}$ |
| Acceleration / Deceleration | $\frac{\text{mm}}{\text{s}^2} \rightarrow \frac{\text{UU}}{\text{ms}^2}$ |